

**Sherpa Power Barrow
Flatbed Accessory
Assembly Instructions**

Model: FLATBED



Components List

Before assembling the Flatbed Accessory, check that you have all of the fixings available. These will be referred to in the groups shown:

A)



B)



C)



Assembling the Flatbed Accessory:

- 1) Lay the flatbed components out as shown:



- 2) The two central pieces are secured in place using the short bolts pictured in A



- 3) Use the handwheel bolts pictured in C to secure the front and sides – these screw into the 6 captive nuts on the underside of the flatbed shown in the below picture (there is enough length in the tubing to allow for adjustment of the side and front positioning if you need to accommodate for larger or smaller loads):



- 4) Finally, once the flatbed is assembled, use the long bolts pictured in B to attach the flatbed to the frame of the barrow – you will need to remove the old bed and the original screws to accommodate the flatbed:





Sherpa Tools

Magic House

Station Road

North Hykeham

Lincoln

LN6 9AL

TEL: 01522 283 020

www.sherpatools.co.uk